

Jens Ritter
Instruments

THE RITTER C-3-S ELECTRONICS

Active / Passive



- 1. Master Volume (Push-Pull Potentiometer to switch between active mode and passive mode).**
- 2. Pickup Balance**
- 3. Dual Potentiometer for BASS Cut and Boost (on Top - only in active mode) and for Mid Cut and Boost (Ring - only in active mode)**
- 4. Dual Potentiometer for TREBLE Cut and Boost (on Top - only in active mode) and PASSIVE TONE (Ring - only in passive mode)**

The RITTER ELECTRONICS is powered by 18 V (two 9V batteries).